Günter Köllner Embedded Development GmbH
Am Rain 24
85256 Vierkirchen, Germany

Datasheet

FLARM BOOSTER

Active Antenna Series

FLARM BOOSTER

Product Number: 69350

Usage:

Amplification of FLARM received signal with bypass of transmit signal.

The FLARM BOOSTER works as a receive preamplifier but bypasses in transmit mode automatically.

Operation mode is displayed by a red and green LED.

Power can be supplied via attached red/black wire as well as over the RX side coax cable.

A built in filter avoids interferences with out-of-band signals

Technical Data

Connectors

Description	Value
RF connector	SMA female
DC Input (1) (2)	FLARM connector Minus: Shield Plus: Center
DC Input (1)	DC cable Minus: black Plus: red

(1) DC inputs can be used alternatively.
(2) Recommended accessories jetvision Bias Tee No. 69400

RF Parameters (typical)

Description	Value
Frequency range	866 MHz – 870 MHz
RX gain	17 dB
Noise figure	< 0.9 dB
Transmit power	15 dBm / 30 mW
TX path through loss	< 0.8 dB
Input and output impedance	50 Ω

RF Parameters

Description	Value
Transmit power (max)	15 dBm / 30 mW
RX to TX switching time (max)	200 ns

DC Parameters (typical)

Description	Value
DC supply voltage	5 - 15V
DC supply current	70 mA
Operating temperature	0 °C – 60 °C

Absolute Maximum Ratings @25°C

Description	Value
Transmit power	20 dBm / 100 mW
DC supply voltage	15 V
Operating Temperature	0 °C - +60 °C
Storage Temperature	-20 °C - +65 °C
Usage	Indoor Use

Block Diagram



jetvision True Air Traffic	Notes:	
Title: Active Antennas Series FLARM BOOSTER	Article No: 69350	Version: 4.0
	Author: Günter Köllner	© Copyright 2022

Receive gain over Frequency

Narrow range:



Wide range:



TX loss over Frequency

Narrow range:



Wide range:

Mechanical Specification

Description	Value
Overall Dimensions	54mm x 42mm x 12mm
Weight	30g

jetvision True Air Traffic	Notes:	
Title: Active Antennas Series FLARM BOOSTER	Article No: 69350	Version: 4.0
	Author: Günter Köllner	© Copyright 2022

Outline

	A	B	C	D
in mm	40	42	54	12



Mounting Instructions

Description	Value
Mounting Direction	vertical, Antenna element upwards
SMA torque	1Nm (1)

(1) If there is no torque spanner just tighten with fingers. Do not overtighten when using standard spanners or other tools.

We reserve the right to make technical changes, which serve to improve the product, without prior notification.

	Notes:	
Title: Active Antennas Series FLARM BOOSTER	Article No: 69350	Version: 4.0
	Author: Günter Köllner	